

## OUTPUT BOX OPERATIONAL LED'S

Note: The OUTPUT BOX LED's only light up when the system is operating.

